



BBQ Quick Charcoal

Price: €11.99

Short Description

380535

- Place the BBQ starter on a tile or other fireproof flat surface and fill it with charcoal or briquettes.
- Light a few firelighters underneath the quick starter.
- The briquettes are piping hot after a few minutes.
- Place the contents of the quick starter on the grill, and the coals will be ready to use in no time.
- A hardwood handle and a heat shield are equipped with the quick starter.

Additional Information:

Dimensions:

16cm diameter x 27.5 cm height